

INSTALLATION INSTRUCTIONS

IMPORTANT

Before assembling your access lighting fixture, please make sure that you carefully read through these instruction sheets. Consider having your fixture installed by a qualified licensed electrician.


NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.




All electrical connections must be in accordance with all ordinances,
Local and National Electrical Codes. These fixtures are intended for
mounting to a standard 4" x 2 1/2"metal octagon outlet box. The box
must be directly supported by the building structure and U.L. Recognized.

STEP BY STEP INSTRUCTIONS

Before starting your installation disconnect the Power by turning off the Circuit Breaker or by removing the fuse at the fuse box. Just turning the light off at the light switch is not sufficient to prevent electrical shock.





COLLECTION

APPLICATION

MODEL NO.

Zenon

Ceiling Fixture

20661LED 20662LED

WHAT WE PROVIDE

- Crossbar
- Mounting Hardware
- Fixture
- 1 x Glass Shade
- LED MOdule

WHAT YOU NEED

- Screwdriver
- Wire Cutters
- Wiring Supplies as Specified by Electrical Code

MOUNT CROSSBAR

If there is an existing fixture remove it. Expose the supply wires from the j-box. Mount the supplied crossbar to the J-Box.

CERTIFICATION: CUL DAMP NO. 20661LED, 20662LED



CONNECT THE WIRES


Gently pull the supply wires. Connect the black fixture wire to the

black supply wire and the white fixture wire to the white supply wire.

Connect the fixture ground wire to the ground wire from the J-Box.


Secure all connections with the supplied wire connectors and U.L.

listed electrical tape (not supplied). Tuck all wires carefully into the J-Box.




MOUNT THE CANOPY

Insert the supplied long screws into the holes on the crossbar. Align the keyholes on the ceiling pan then secure the ceiling pan flush against the ceiling.



ATTACH THE GLASS SHADE

Loosen nuts on the Clips as shown in drawing A1,place the Shade on canopy and tighten clips as shown in drawing A2.



RESTORE THE ELECTRICITY AND CHECK THE OPERATION OF YOUR **NEW ACCESS FIXTURE**

